

TEL P12XL prober dual load port

Main System: Prober (QTY 1)

Handle System: Pincette (QTY 2)

Factory Interface: FOUP (QTY 2)

Software Version: Rby00-R014.083Z

CIM: RS232

Process: Test